

FIG. 1




Fig. 2




Fig. 3

Equipment ID	Kind	Number of Speakers	Speaker ID	Coordinate Position	Number of Channels	Delay Time
001	TV	3	A,B,C	(10,0,0)	3ch	...
002	Radio-Cassette	2	D,E	(0,0,0)	2ch	...
003	Stereo	2	F,G	(20,0,0)	2ch	...
004	PC	2	H,I	(20,20,0)	2ch	...
005	Karaoke	1	J	(0,20,0)	1ch	...
006	Sub-Woofer	1	K	(10,0,0)	0.1ch	...
...
101	Equipment In other Rooms	2	X,Y	-	2ch	...
...

Fig. 4




Fig. 5




Fig. 6

Combination to be selected	
<p>There are a plurality of candidates of combinations.</p> <p>Select any one out of them.</p>	
<input checked="" type="radio"/>	Radio-Cassete (1ch) and Stereo (1ch) (Recommended)
<input type="radio"/>	Radio-Cassette (1ch) and TV (1ch)
<input type="radio"/>	Stereo (1ch) and TV (1ch)
<input type="radio"/>	TV (2ch) only
<input type="radio"/>	Radio-Cassette (1ch) and Karaoke (1ch)
<input type="radio"/>	Stereo (1ch) and PC (1ch)
<input type="radio"/>	Karaoke (1ch) and PC (1ch)
<input type="button" value="OK"/>	<input type="button" value="CANCEL"/>

Fig. 7




Fig. 8




Fig. 9